Yealink

Open your phone’s web interface and go to Account.
Enter the following information:
ID name: your SIP number (111111, for example) from Settings => User management
User name: your SIP number (111111, for example) from Settings => User management
Password: your password for the SIP number from Settings => User management
SIP server: login.smarttelplus.eu
Port: 5060